



prolift 430R

opener for **roller doors**



User manual

Toll free helpline
0800 073 0112

Please have your serial number and model name available before calling.
www.merlingo.com

Important safety instructions for operation

It is vital for the safety of persons to follow all instructions. Save these instructions.

WARNING Do not allow children to play with door controls. Keep remote controls away from children. The appliance is not intended for use by young children or infirm persons without supervision.



Merlin strongly recommends the use of optical safety beams on all sites as this is a non-contact system



Watch the moving door and keep people away until the door is completely opened or closed.



Use caution when operating the manual release with the door open since it may fall rapidly due to weak or broken springs or an imbalanced door stand well clear of the path of the moving door.



Frequently examine the installation, in particular cables, springs and mountings, for signs of wear damage or imbalance. Do not use if repair or adjustment is needed since a fault in the installation or an incorrectly balanced door may cause injury.



Your door and opener should be serviced at least annually to ensure safe operation.



Each month check that the drive reverses when the door contacts a 50mm high object placed on the floor. If check fails contact your Merlin Dealer or Authorised Merlin Installer to adjust the force sensitivity.



Force sensitivity should only be adjusted by a professional installer able to test force at the leading edge of the door.



This appliance is intended for use in single household domestic dwellings only. The appliance should not be used in multi-household or high frequency use dwellings.



Disconnect electric power to the garage door opener before making any repairs or removing any side covers.



To prevent fire or shock hazard, do not expose the opener to rain or moisture.



To avoid electrical shock do not open the cabinet without disconnecting the opener from the mains.

Welcome

Thank you for purchasing the Merlin Prolift roller door opener. This product combines convenience with security. You can operate the door from a remote control radio transmitter or from a push-button inside your garage. One touch of the remote control button or internal push button will activate the opener and the door will open (or close) automatically. The door may be stopped in any position during the opening cycle by pressing either button. You can close the door by pressing the button again. This ruggedly built garage door opener will provide years of safe and dependable service. Please take a moment to complete and send in the warranty card included with this product. Also please note your serial number and purchase details. We are proud of our product and want to provide the best after sale service possible. Please feel free to contact us if you have any suggestions or comments.

Manually operating the door

The garage door can be disengaged from the opener to enable the door to be operated manually.




WARNING Stand clear when releasing the door – if the door is unbalanced it may move suddenly.

To disengage the opener

Pull the red release cord down.

To re-engage the opener


Push the lever (attached to the red release cord) upwards and move the door slightly to allow the gear to engage. The door can be re-engaged in any position.



Release cord & clutch

Operating from a remote control transmitter

Your remote control transmitter has two buttons. One large button and one small button. You can control two products with the two buttons. For example a gate opener and a garage door opener. A press on a remote control transmitter button will open, stop or close the door.



**Remove visor clip.
Press cover down
then slide off to
expose battery.**

If your remote control transmitter has no effect, move closer to the opener. Radio signals can be blocked or reduced by many external factors. There is a battery inside the remote control transmitter which requires periodic replacement. A fresh battery will give better performance than an old battery.

Operating from a push button or wall box



Push button operation is identical to operation from a transmitter, except that there is no radio signal to be considered.

Repeated button pushes cause the door to Open, Stop and Close, as described above.

One green push button is on the front face of the opener.

The wall control box buttons have similar functions to your transmitter.

Setting the door travel limits





The procedure for setting the door travel limits differs depending on which side of the garage door the opener has been fitted.

STEP 1:

To access the limits rotate the limit cover clockwise to the open position. Remove the green control panel cover from the left front face of the opener.

STEP 2:

As viewed while looking out of the garage through the doorway, is the opener on the right-hand or left-hand side?



Setting door travel limits for right-hand mounting only

STEP 1: Inspect the option switches on the control panel. The switch marked 'Roller L:R' should be moved to the R position.

STEP 2: Set the bottom limit of travel.

Connect the mains power to the opener and switch the power on. Pull the manual release to disengage the door from the opener.

Lower the door manually to the fully closed position.

Observe the red LED on the control panel. It should be flashing. (If the red LED is on continuously, rotate the front actuator arm clockwise. If the green LED is on continuously, rotate the rear actuator arm anti-clockwise.)

Rotate the front limit-actuator-arm anti-clockwise until it contacts its microswitch and the red LED stays on continuously.

STEP 3: Set the upper limit of travel.

Raise the door manually to the fully open position.

Observe the green LED on the control panel. It should be flashing. (If it isn't then rotate the rear limit-actuator-arm anti-clockwise away from its microswitch.)

Rotate the rear limit-actuator-arm clockwise until it contacts its microswitch and the green LED stays on continuously.

The limits are now largely set in the correct position. However the door travel can be further adjusted using the fine adjustment screws.

Each turn of the screw results in around 5mm of door travel.

After the limits have been set close the limit cover.

Setting door travel limits for left-hand mounting only

STEP 1: Inspect the option switches on the control panel. The switch marked 'Roller L:R' should be moved to the L position.

STEP 2: Set the bottom limit of travel.

Connect the mains power to the opener and switch the power on. Pull the manual release to disengage the door from the opener.

Lower the door manually to the fully closed position.

Observe the red LED on the control panel. It should be flashing. (If the red LED is on continuously, rotate the rear actuator arm anti-clockwise. If the green LED is on continuously, rotate the front actuator arm clockwise.)

Rotate the rear limit-actuator-arm clockwise until it contacts its microswitch and the red LED stays on continuously.

STEP 3: Set the upper limit of travel.

Raise the door manually to the fully open position.

Observe the green LED on the control panel. It should be flashing. (If it isn't then rotate the rear limit-actuator-arm anti-clockwise away from its microswitch.)

Rotate the front limit-actuator-arm anti-clockwise until it contacts its microswitch and the green LED stays on continuously.

The limits are now largely set in the correct position. However the door travel can be further adjusted using the fine adjustment screws.

Each turn of the screw results in around 5mm of door travel.

After the limits have been set close the limit cover.



WARNING: The door is not safe for unsupervised operation until the force sensitivity has been set.

NOTE Repeated operation of the opener in a short period of time during the setting of force sensitivity may trigger the thermal cutout of the motor. In this case you will have to wait for approximately five minutes for the motor to cool sufficiently to continue the installation process. If the unit has overheated you will hear the relays clicking in response to the transmitter or pushbutton but the motor will not operate. After cooling down, normal operation is able to resume.

Setting up wireless controls

Wireless controls can operate the opener, or the opener's courtesy lamp, by sending coded radio signals. These coded signals use high-security code-hopping.

Wireless controls can be hand-held or fixed to walls, such as a wireless keypad, or a wireless wall-switch.

Up to 20 Merlin wireless controls can be learned by the opener. After this, the 20th wireless control is over-written in the opener's memory.

All wireless controls can be deleted from the opener's memory.

There is a red learn button under the green control panel cover on the front face of the opener. The small button on a Merlin M-122 wired wall-switch can also be used as the learn button.

If a setting is enabled in the opener, then it is possible to use any existing learned wireless control as a learn button. (See separate section following.)

To learn a remote button to operate the opener:

Press the learn button for 1-2 seconds, until the courtesy lamp begins to flash slowly.

Press the desired remote button, wait 1 second, press the desired remote button again. The courtesy lamp will stop flashing once learning is complete.

To learn one remote button to operate the opener and another to operate the lamp:

Press the learn button for 1-2 seconds, until the courtesy lamp begins to flash slowly.

Press the desired remote button for control of the opener, wait 1 second, press the desired remote button for control of the courtesy lamp. The courtesy lamp will stop flashing once learning is complete.

To delete all remote controls from the opener's memory

Press and hold the learn button for eleven seconds, until the courtesy lamp stops flashing. After six seconds it will flash fast as a warning. If you release the learn button during this warning period then the memory will not be wiped.

Remote transmitter learning

Remote Transmitter Learning (RTL), when enabled, allows any existing learned wireless control to be used as a learn button for the learning of additional wireless controls. Note that this feature trades convenience for security. If it is chosen to disable RTL (the default setting at manufacture is enabled) then the level of security is increased.

To enable or disable RTL:

Remove the green control panel cover to expose the setup controls. Identify the red learn button and the black program button.

Hold both of these buttons down for three seconds until the courtesy lamp begins to flash. Release both buttons.

Six flashes confirms that RTL is now enabled.

Four flashes confirms that RTL is now disabled.

To place the opener in learn mode using RTL:

Select any two or four button Merlin hand held remote control that is already learned in to the opener. Call this the master remote.

Press the master remote north and south buttons together for 2-3 seconds.

The courtesy lamp on the opener will begin to repeat a cycle of flashing three times and pausing. If you have several openers that operate from this master remote, then all these openers will begin to flash their courtesy lamps.

Press the button on the master remote that would normally operate the desired opener. Now that opener will go into learn mode, and any other openers that were flashing will return to their normal standby state.

The courtesy lamp on the opener that is in learn mode will begin to flash slowly. If no signals are received for 20 seconds, the opener will revert to its normal standby state.

To learn a button to operate the opener:

Press the desired remote button, wait 1 second, press the desired remote button again. The courtesy lamp will stop flashing once learning is complete.

To learn one remote button to operate the opener and another to operate the lamp:

Press the learn button for 1-2 seconds, until the courtesy lamp begins to flash slowly.

Press the desired remote button for control of the opener, wait 1 second, press the desired remote button for control of the courtesy lamp. The courtesy lamp will stop flashing once learning is complete.

Checking the force sensitivity

Regularly check the force sensitivity feature using a 50 mm block of wood as an obstruction. The door should reverse promptly on contact. If check fails contact your Merlin Dealer or Authorised Merlin Installer to adjust the force sensitivity.

Force sensitivity should only be adjusted by a professional installer able to test force at the leading edge of the door.

Troubleshooting

There are no user serviceable parts inside the opener. The power cord is not intended for replacement by the user. Please refer to your Merlin dealer in the event that replacement is required. Contact your Merlin dealer or Authorised Merlin Installer for any service requirements

Opener does not work at all.

May be no power. If the lamp is still on then the motor may have temporarily shut off to cool down. SOLUTION: Plug another appliance into the power point to check power. Wait five minutes for the motor to cool.

Courtesy lamp flashes when door stops.

This is a warning that your door was obstructed and couldn't reach its normal stopping position. It may also be a warning that your door has become very heavy to operate.

SOLUTION: Look for anything blocking the beam sensor. Is the beam aligned correctly? Release the manual release and check the door can be operated easily by hand. Get your door repaired or serviced if it is heavy to move by hand.

Transmitter range is shorter than normal.

Your transmitter battery may be going flat. The antenna wire out of the door opener may be damaged.

SOLUTION: Replace the transmitter battery. Uncoil the antenna wire if it is coiled up.

Transmitter doesn't work some times.

There may be occasional radio interference in your area. Your transmitter battery may be going flat. Transmitter may not be learned.

SOLUTION: Check for nearby wireless products that could be interfering. Replace the transmitter battery. Learn remote.

Transmitter doesn't work at all.

Your transmitter battery may be flat.

SOLUTION: Replace the transmitter battery.

Wall button doesn't work.

Switch or wiring may be broken or damaged. Connection may be loose.

SOLUTION: Replace switch. Replace wiring. Check connections each end.

Door operates unexpectedly.

A transmitter may be operated accidentally.

SOLUTION: Check all of your transmitters to be sure they are not being operated by items placed on top of them.

Door is open when you arrive home, yet you pressed the button to close it when leaving.

Door may have sensed an obstruction and automatically reversed to the open position.

SOLUTION: Make sure you watch the door close fully before driving away.

Door stops part way up.

There is an obstruction being sensed. Settings for force sensitivity or door travel limits may have changed.

SOLUTION: Pull the manual release and check that the door can be operated easily by hand through the full range of movement. Adjust or repair the door. Contact your Merlin dealer or Authorised Merlin Installer to adjust the force sensitivity.

Door closes partly then opens again by itself.

There is an obstruction being sensed. Settings for force sensitivity may have changed.

SOLUTION: Pull the manual release and check that the door can be operated easily by hand through the full range of movement. Adjust or repair the door. Contact your Merlin dealer or Authorised Merlin Installer to adjust the force sensitivity.

Courtesy lamp does not go.

Bulb may be blown.

SOLUTION: Remove the lamp cover and replace the bulb.


Door or opener has become more noisy.

Door may be worn.

SOLUTION: Pull the manual release and check that the door can be operated easily by hand through the full range of movement. Adjust, lubricate or repair the door.

Specifications

Replacement light bulb	E27 45mm Round, 40W maximum, RC preferred
Mains power required	220V to 240V, 50Hz, single phase AC, earthed
Maximum rated torque	70Nm
Stand-by power consumption	3W maximum
Operating power consumption	900W maximum



Rolling shutter door

Requirements for garage doors

Height:	maximum 3m
Width:	maximum 6m
Gross door mass:	maximum 200kg

If any of these values are exceeded safety beams must be fitted or the leading edge force of the garage door tested.



The force required to move the garage door should not exceed 30kg.

Warranty - please return your warranty card

Garage Door Opener Limited Warranty

Merlin warrants to the original purchaser ("the Buyer") that the Merlin garage door opener ("the Unit") sold under this warranty will be free from defects in materials and workmanship for a period of 24 months from date of purchase.

Accordingly if the Unit fails due to defects in materials or workmanship within the warranty period Merlin will, provided the defective part or Unit is returned freight and insurance prepaid and well packaged to the nearest address listed in this manual, undertake to repair or, at its option replace, any defective part or Unit and return it to the Buyer at no cost. Repairs and replacement parts are warranted for the remaining portion of the original warranty period.

Limited warranty on motor. After 24 months and through to 60 months, Merlin will furnish a replacement motor, if it is found to be defective; free of charge. Labour costs will be charged.

Where the Unit has been installed by an authorised installer, Merlin will furnish replacement parts free of charge through the authorised installer. A service fee on site service may apply.

LIMITATIONS It expressly excludes any batteries or light bulbs and malfunctions or defects to the Unit or its operation due to any of the following:

- A Failure to observe installation, adjustment, maintenance or operating instructions provided with the Unit;
- B Incorrect installation, operation or adjustment of the garage door to which the Unit is fitted;
- C Connection to any garage door outside the specifications set out in the owners manual;
- D Any modification or repair to the Unit carried by a person not authorised to do so by Merlin;

- E Radio or any other electrical or electronic interference;
- F Faulty or unsuitable electrical wiring of the building to which the Unit is attached;
- G Faulty or flat batteries in the remote control transmitter;
- H Where the defect is due to: conditions other than normal domestic use or dirt, misuse, neglect, fire, accident, electrical storm or other act of God.

This warranty is void if the serial number has been altered, defaced or moved.

The liability of the Distributor for any loss or damage or injury arising directly or indirectly from any defect in the goods supplied is limited to the replacement or repair of such goods or to damages not exceeding the invoice value of such goods at the option of Merlin.

FUTURE MODIFICATIONS Merlin may modify any existing or future model of the Unit without the obligation to incorporate these modifications into Units already manufactured or into the Unit to which this warranty applies.

GENERAL This warranty is the only Warranty made by Merlin. All other warranties, representations and conditions of any kind, express or implied, are hereby excluded. Nothing in this warranty is intended to have the effect of contracting out of the provisions of the law except to the extent provided by that law and all provisions of this warranty shall be read and modified to the extent necessary to give effect to that intention. This warranty does not deprive the Buyer of any rights conferred upon them by any applicable law or statute in their country of purchase.

Proof of date of purchase may be required when making a claim under warranty. In the event that the Buyer is unable to provide adequate proof of purchase the date of warranty will apply from date of shipment from the Distributor to the Reseller.

NOTE We request that you attach your sales docket or invoice to this manual to enable you to establish the date of purchase in the unlikely event of a service call being made.

In-warranty service

During the warranty period, if the product appears as though it may be defective, call our toll free service before removal of the unit. A Merlin technician will diagnose the problem and promptly supply you with the parts for “do-it-yourself” repairs, or provide you with shipping instructions for a factory repair or replacement. If an Authorised Installer installed your unit you must call them for prompt on-site service.

Merlin service centres

England

Phone toll free 0800 073 0112

Fax toll free 01709 514 534

www.merlingo.com

Merlin does not accept responsibility for damage or injury resulting from installing this opener. Merlin reserves the right to change the design and specification without prior notification. Some features or accessories may not be available in certain markets or areas. Please check with your distributor.